		-						
NO.	(04)	6	80	14	23			
Quant	4	4	2	2	0	Frame	Setup Instructions 1. Take all the parts out of the bags according to the assembly diagram. 2. Make sure that all the correspond 3. Now start pushing the pipes togo difficult you can slightly twist the p spring pop up on place. 4. Its time to get your hands cleane the printed fabric. Feed the fabric fr feed only a few feet, then stand the the bottom, now close the Zipper. 5. You can set up the feet in the por stand, lift the fabric panels and fit c 6. To lock the frames together you of they are designed tight so they lock 7. If you have a header in the kit yo clear plastic clips.	
Quantity Confirm						ne	all the p sure t you ca op up c an set ft the f the f	
							sarts ou ric. Feet, the parts out of the	
NO.	35	27	00	102°	84°		Instructions Instructions The parts out of the bar o the assembly diagra re that all the corresp rt pushing the pipes to u can slightly twist th up on place. to get your hands cleater few feet, then stand for the fabric panels and for the fabric panels and for he fabric panels and for the fabric panels and for the stand he frames together your hander in the kit ave a header in the kit c clips.	
Quant	6	\sim	2	2	N	Frame	 Setup Instructions 1. Take all the parts out of the bags and lay them on the ground according to the assembly diagram. 2. Make sure that all the corresponding numbers are correct. 3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place. 4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper. 5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet. 6. To lock the frames together you can use the "S" shaped brackets, they are designed tight so they lock well. 7. If you have a header in the kit you can fix to the top by using the clear plastic clips. 	
Quantity Confirm						ne	and lay d as no pom the run frame arts tog un the fe an use well.	
							w you a round of the "S"	
NO. Q	(E2)		(R2)				Angelfish Angelfish them on the grou ther are correct if they firmly clic ther to make the p then slide the et. to the top by us	
Quantity	2	<u> </u>				Frame	ground ect. ect. click, if the fab the fab	
Confirm							cking the the the	
rm NO.							ne ts,	
Q						F		
antity		\				Frame		
Confirm							heter	
NO.								
Quar						Frame		
Quantity Confirm						ne		
onfirm								
NO.							nitor (
Quantity						Frame		
						le		
Confirm								
NO.			40"	32"	22.6"			
Co						TV kit		
Confirm							2006 mm (7)	

WLM-ANGELFISH A

