## WLM-CARIBBEAN C – Curved Header



## Setup Instructions

- 1. Take all the parts out of the bags and lay them on the ground according to the assembly diagram.
- 2. Make sure that all the corresponding numbers are correct.
- 3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place.
- 4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper.
- 5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet.
- 6. To lock the frames together you can use the "S" shaped brackets, they are designed tight so they lock well.
- If you have a header in the kit you can fix to the top by using the clear plastic clips.

Frame		Frame			Frame			Frame		Ţ	Frame			Frame	7	TV kit	Shippin	g Case	Shipping Case accessories
(E) 4	clear	2													22.6"		CA900		2000E*2+WL43C*1
27) 2	clear	2													32"		CA500		
23 4	WL43C	1		34	1					\		\			40"				
05 4	90°	4		16	2					\									
03 4	35	4		17	2	\													
NO. Quantity Confirm NO.		Quantity Confirm NO. Quantity Confirm NO.	onfirm	NO. Q	uantity (	Confirm	NO.	Quantity C	onfirm	No. Q	uantity C	onfirm	NO. Q	Quantity Confirm NO. Quantity Confirm NO. Quantity Confirm NO.		Confirm	NO.	Confirm	

