WLM-MANDARIN A



Setup Instructions

- 1. Take all the parts out of the bags and lay them on the ground according to the assembly diagram.
- 2. Make sure that all the corresponding numbers are correct.
- 3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place.
- 4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper.
- 5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet.
- 6. To lock the frames together you can use the "S" shaped brackets, they are designed tight so they lock well.
- 7. If you have a header in the kit you can fix to the top by using the clear plastic clips.

Frame	Fre	Frame	F	Frame		Frame	me		Frame		Frame	TV kit		Shippin	Shipping Case accessories
(102°) 2	(22) 1		03 2	2								22.6"		CA900	2000A*2
84 0 2	(²²) 2											32"		CA500	
13 2	23 4											40"			
35 4	06 2														
27 1	05 2														
NO. Quantity Confirm NO. Quant	irm NO. Qua	ntity Confirm	NO. Q	uantity Co	onfirm N	IO. Quai	ntity Confir	m NO.	Quantity	Confirm NO	. Quantity Confirm	NO.	Confirm	NO. Confirm	Confirm

