NO.	27	35	3	84 °	1020)																
Quantity Confirm	-	4	2	N	2	Frame	7. It yo clear pla	6. To Ic they are	5. You stand, l	4. Its ti the prir feed on the bot	3. Now difficult spring p	2. Makı	1. Take accordir	Setu								
y Confir						Ð	7. It you have a h clear plastic clips.	e design	can set u ift the fi	ime to g ited fabi ily a few torn, no	3. Now start pushing t difficult you can slightl spring pop up on place	e sure th	all the p ng to the	ul dr								
m NO.	05	06	23)	i header is.	rames to ed tight	up the fe abric par	et your l ric. Feed feet, th w close ⁻	n slightly n place.	nat all th	arts out e assem	struc								
Quant	N	N	4	N	<u> </u>	Frame	7. It you have a header in the kit you can fix to the top by using the clear plastic clips.	for lock the trames together you can use the "S" shaped brackets, they are designed tight so they lock well.	5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet.	4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper.	3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place.	Make sure that all the corresponding numbers are correct.	 Take all the parts out of the bags and lay them on the ground according to the assembly diagram. 	Setup Instructions								
Quantity Confirm						ле	it you ca	you can lock we	e positic fit on th	eaned as ric from d the fra er.	togethe he parts	ponding	bags and ram.	S								
irm NO.					03		n fix to	use the II.	n that y ne feet.	s now yo the rour me up tl	er until ti togethe	numbe	lay the									
). Quantity					2	Frame	the top I	deus "S.	ou want	u are re 1d edges 1en slide	ney firm er to ma	rs are co	m on th									
						me	guisn Ág	bed brac	to erec	ady to h 5 of the e the fal	ly click, ke the lo	rrect.	e groun									
Confirm							the	kets,	t the	andle frame, oric to	if ocking		<u>L</u>	and a list of the								
NO. Q														State of the light			mandarin				-1	
uantity						Frame								To Lot a Lot of the			5		•	VALEN		≶
Quantity Confirm														A Martin	ALC AND		•					M
n NO.							-											OCLANS REFS &			••[]	- N
Quantity						Frame												AQUARIUMS				-MANDARIN B
ity Confirm						le																
irm NO.							-									ADUARIUMS*						A
						Fra																
Quantity C						Frame																
Confirm																						
NO.			40"	32"	22.6"																	
						I VT											3 B	I		Ð		
Confirm						kit		144			976						Ŵ					

