NO.	37	6	13	840	102°)			
Quantit	-	-	-	<u>ح</u>	-	Frame	Setup 1. Take all t according t according t 2. Make su 3. Now stau difficult you spring pop 4. Its time t the printed frame, feed fabric to th 5. You can 5. You can stand, lift th 6. To lock t they are de 7. If you ha		
Quantity Confirm						Ð	Setup Inst Setup Inst 1. Take all the paraccording to the paraccording to the paraccording to the paraccording pop up on 4. Its time to get the printed fabric to the bott fabric to the bott 5. You can set up stand, lift the fabric to the fabric 6. To lock the franct the paraccord the paraccord the fabric fabric to the bott fabric fabric to fabric to fabric fabric fabric fabric fabric fabric fabric fabric fabric to the fabric fabric to the fabric fabric fabric to the fabric		
-		RZ	27	35	90°)	 Setup Instructions 1. Take all the parts out of the bags and lay the according to the assembly diagram. 2. Make sure that all the corresponding numl 3. Now start pushing the pipes together until difficult you can slightly twist the parts together until difficult you can slightly twist the parts together until difficult you can slightly twist the parts together until difficult you can slightly twist the parts together until difficult you can slightly twist the parts together until difficult you can slightly twist the parts together until difficult you can slightly twist the parts together until difficult you can slightly twist the parts together until difficult you can set up the fabric. Feed the fabric from the roof frame, feed only a few feet, then stand the frame fabric to the bottom, now close the Zipper. 5. You can set up the feet in the position that stand, lift the fabric panels and fit on the feet. 6. To lock the frames together you can use th they are designed tight so they lock well. 7. If you have a header in the kit you can fix t clear plastic clips. 		
Quanti	-		Ν	0	4	Frame	tions of the the bly diaged bly d		
Quantity Confirm						ē	ponding togethe togeth	-1	
rm NO.	03	05	10	23	(F2)		I lay the r until t togethe s now yc the rour the fram per. n that yv e feet. use the ill.		
. Quantity	ω	сл U	N	0	N	Frame	 Setup Instructions 1. Take all the parts out of the bags and lay them on the ground according to the assembly diagram. 2. Make sure that all the corresponding numbers are correct. 3. Now start pushing the pipes together until they firmly click, if difficult you can slightly twist the parts together to make the locking spring pop up on place. 4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the frame, feed only a few feet, then stand the frame up then slide the fabric to the bottom, now close the Zipper. 5. You can set up the feet in the position that you want to erect the stand, lift the fabric panels and fit on the feet. 6. To lock the frames together you can use the "S" shaped brackets, they are designed tight so they lock well. 7. If you have a header in the kit you can fix to the top by using the clear plastic clips. 		
ity Confirm						le	ed brack	-1	\leq
îrm NO.		clear	\bigcirc	ω	(16)		International action of the second se		WLM-
		ar G	09	34	6	Fra	bow bow bow bow bow bow bow bow	J	
antity		4	2	→	N	ame	OSERE		SC
Quantity Confirm									SPREY
n NO.									ΕY
						Frame		900	B
Quantity Confirm						le		3	Ч
							Media Cable		Straight
NO. QL						Ţ			<u>i</u> g
Quantity						Frame			ht
Confirm									He
			4		22		Monitor Cord		Header
NO.			40"	32"	22.6"	L			ler
Confirm						TV kit			
m.									

