WLM-ATLANTIC C – Curved Header



Setup Instructions

- according to the assembly diagram. 1. Take all the parts out of the bags and lay them on the ground
- 2. Make sure that all the corresponding numbers are correct.
- spring pop up on place. difficult you can slightly twist the parts together to make the locking 3. Now start pushing the pipes together until they firmly click, if
- 4. Its time to get your hands cleaned as now you are ready to handle the printed fabric. Feed the fabric from the round edges of the fabric to the bottom, now close the Zipper. frame, feed only a few feet, then stand the frame up then slide the
- stand, lift the fabric panels and fit on the feet 5. You can set up the feet in the position that you want to erect the
- they are designed tight so they lock well. 6. To lock the frames together you can use the "S" shaped brackets,
- clear plastic clips. 7. If you have a header in the kit you can fix to the top by using the



