



Fully Assemble The Frame



Once Marked With Marker, Remove Monitor Bracket



Put Graphic On The Frame



Make Slits With A Sharp Knife Where The Bolts Should Penetrate Graphic



Reattach Monitor Bracket To Front Of Graphics And Tighten



Attach Mounting Rails Onto Back Of Monitor

Hang Monitor Back Onto Support Bars